

CTS-AA chassis-service mode

Models: Pacific model PTV 3604
Pacific model PTV 5102 (values with red)
Tecnimagen model 14TXN (values with black)

SAA 5531PS/M4/0329 microprocessor + 24C04 smd
SAA 5541PS/M5/0330 (for model : Pacific PTV 3604)
STV 2246C=jungle
TDA 1771=vertical stage
TDA 8943=audio
TDA 4605=power supply
BUL 310FP + 40337-54(Orega flyback trafo)=horizontal stage
OREGA 40346-49=Chopper trafo
313010831030
10694870

Service menu:

Switch-off tv.(mains switch)
Put the pin 7 of microprocessor to ground.(strap)
Power-on tv:a S appear in the left down corner.
Remove the strap of pin 7.
Press OSD (or RECALL) button on remote control.
SERVICE V1.1

AFC COARSE 05 06
AFC FINE 2C 2B
AFC COARSE LP 07 07
AFC FINE LP 40 40

CVBS AMP 10 10
AGC START 27 26
AGC GAIN 00 00
MANUAL C-O 00 00

R CUT-OFF 21 1F
G CUT-OFF 20 23
BRIGHTNESS 20 20
CONTRAST 20 20

R GAIN 19 38
G GAIN 13 36
B GAIN 11 33
BELL FILTER 00 00

APR THRESH 08 0B
HOR SHIFT 28 35
VERT AMP 39 31
TXT SHIFT 01 01

SYS OPTION 00 (or 03)
MENU OPTION 00 00
AFC ADJUST 00 00
AFC LP ADJ 00 00

Parameter modification:V+ & V- buttons
Select groupe(four parameters) with P- button
Store :with OSD(RECALL) button on RC
SYS OPTION:00(SOUND EUROPA BG)
03(EUR+DK)
Leave the service menu: Switch-off TV(mains switch)